

Installation Guides

Aluminium Venetian Blinds Installation

Installing your blinds is really easy with our simple installation guides!

ITEMS:

1. Venetian blind
2. Brackets and screws
3. Hold down clips (optional)

TOOLS REQUIRED

1. Cordless drill
2. Pencil

Aluminium Venetian Blinds Installation Inside Fit

Step 1 Inside fit



Unwrap your Venetian blind, take care not to bend any slats. Once they are bent you cannot bend them back into place without leaving a kink.

Using a pencil mark 9cm and 12cm in from the inside edge of the frame. Repeat at the opposite edge. Place the brackets in the middle of the marks and screw into place.



For blinds requiring more brackets space them evenly making sure they don't interfere with the tape rolls inside the head rail.

Step 2 Inside fit



When fitting the blind, leave the blind pulled up.

On the front of the head rail at the top there is a lip. Hook this lip over the front of the bracket then push the back of the head rail up into the bracket until you hear it click into place.

Step 3 Inside Fit



This is how it should look once completed.

Pull the cords toward the middle of the blind, this releases the cord lock allowing you to lower the blind. Use the wand to control the angle of the slats.